

Maintenance and Warranties Park Series Pump Tracks

MPT01V4 RHYTHM STRAIGHT

MPT02V4 SPEED RING MPT03V4 QUADRAGON

MPT04V4 RAUPO MPT05V4 KAPITI

MPT06V4 WORLD CUP MPT07V4 ADVANCED

Or any custom version of the above manufactured by Parkitect and supplied by Parklife.

Modular Pump Tracks are subject to heavy use by a range of users on various wheeled equipment in unsupervised outdoor environments and are subject to vandalism.

The asset owner is responsible for maintaining a program of routine inspections and maintenance to ensure public safety and extend the asset's life.

General

Routine inspections and maintenance are the sole responsibility of the track's owner.

A maintenance record must be completed, noting the date, type of maintenance, comments, completion by, and signature.

Parklife is to be contacted immediately if any issues are detected.

Parklife must authorise any significant repairs and supply replacement parts. Failure to do so voids the warranty and may result in serious injury.

Pesticides and Herbicides are to be kept well clear of the modules.

Vehicles (including maintenance mowers) must be kept at least 1m from the modules.

Shrubs are to be maintained at least 1m from the modules.

New trees are to be planted at least 4m from the modules.

The following is a guideline only.

Installation

If a Parklife approved installer did not install the pump track, ensure it was installed according to Parkitect's installation drawings.

Weekly Inspection & Maintenance

Check all modules and panels are present and fully bolted together.

Check for continuity, including alignment of joints between each module for a smooth transition.

Check the 2m safety clearance area around the modules at any given point for hazards, including but not limited to vertical objects (park furniture, fences, barriers, etc), sharp objects, debris, potholes, and vegetation.

Check for anything on the track that would cause the user to slip, such as sand, soil, leaves, oil, etc.

Clear debris on the riding surface with a broom and/or leaf blower.

Check the safety signage is visible.

Monthly Inspection & Maintenance

Check no vegetation is growing up under the modules.

Check no modules are sitting in standing water.

Clean the riding surface with a soft brush and water as required.

Annual Inspection & Maintenance

Check all modules are firmly placed on a level, compact, free-draining surface and that the track's feet have not sunken into the ground.

Check the Glass Fiber Reinforced Polymer (GFRP) riding surface and repair as per below:

Minor scratches

Make good with Resene D34C Lumbersider Cool Colour to match the track colour. Request the RAL colour from Parklife.

Minor scrapes

Make good with a Solarez Polyester Resin UV Cure Repair Kit and finish with Resene D34C Lumbersider Cool Colour to match the track colour. Request the RAL colour from Parklife.

Grafitti

Parklife should be contacted should the equipment be graffitied so they can best advise the right strategy to remove.

Contacts

Parklife Ltd 09 871 0256 info@parklife.co.nz www.parklife.co.nz

Warranties

MPT01V4 RHYTHM STRAIGHT
MPT02V4 SPEED RING
MPT03V4 QUADRAGON
MPT04V4 RAUPO
MPT05V4 KAPITI
MPT06V4 WORLD CUP
MPT07V4 ADVANCED

Or any custom version of the above manufactured by Parkitect and supplied by Parklife.

Parklife passes on to the asset owner the benefit of the Parkitect Ltd Product Warranty, issued upon project completion.

Parklife provides a 2-year Installation Warranty.

Subject to Parklife Terms and Conditions.



General Warranty

What does this Warranty cover?

Hereby PARKITECT grants a worldwide voluntary manufacturer's warranty ("Warranty") for all of its Modular Pumptrack Products ("Products") limited to the first purchaser of the Product ("Client"). This Warranty covers defects in materials and workmanship on Products sold completely assembled by PARKITECT or an authorized PARKITECT Reseller, installed and maintained in accordance with the Owner's Manual and Assembly Guide. This Warranty gives you specific rights, and you may also have other rights, which vary from state to state.

How long is the Warranty valid?

To the extent permitted by law and unless a shorter duration is stipulated by law, any warranties implied by law are limited in duration to maximum:

- 10 years: for the functional strength of all precast concrete Modules,
- 5 years: for the functional strength of all: galvanizing and non-coated steel/metal parts, solid plastic parts and wooden parts preserved by oil impregnation on a regular basis, depending on local weather conditions,
- 2 years: on surfaced plywood boards, wood surface treatment, as well as galvanizing, sealants & paint coatings,

from the date of the transfer of risks of the Product to the Client.

Repaired or replaced Products are covered for the remainder of the original Warranty period and subject to the conditions outlined in the original Warranty, to the extent permitted by law.

What does this Warranty not cover?

- Any Defect caused by exposure to: vandalism, misuse, intensive strain, unforeseen environmental conditions, accident, neglect, improper handling, improper transportation, abuse, an act of God, etc., is not covered.
- Any Defect related to: improper assembly, improper installation, non-compliance with recommended maintenance and care procedures, improper or incorrectly performed maintenance, repairs performed by someone other than an authorized PARKITECT Reseller, use of aftermarket products or devices in conjunction with the Product, alteration of the Product, etc., is not covered.
- Any Defect caused by normal "wear and tear" and exposure to weather, such as: loose or unscrewed nuts and bolts, worn down riding surface, chips and scratches on the riding surface, discolouration of surfaces and other cosmetic issues, cosmetic wood deformation, splintering and resin leaks, etc., is not covered.



General Warranty

- Any Defect claimed more than 60 days after the first detection of the Defect, or 60 days after the Defect should have been detected during a regular inspection, is not covered.
- Any Defect on Second Hand Products such as: EX-demonstration Products, Used Products, EX-rental products, even if purchased directly from the manufacturer, is not covered.

How do you make a Claim under this Warranty?

Your first point of contact for any Warranty Claim is whoever sold you the Product, be that PARKITECT AG, or any of its: Reps, Resellers, Dealers or Distributors within the world wide distribution network ("PARKITECT Contact").

To make a Claim under this Warranty, notify your PARKITECT Contact of the Defect. You will be provided with a Warranty Claim Form and instructions about how to proceed.

What will PARKITECT do upon receiving a Claim?

Upon receiving a complete Claim, PARKITECT will open a Warranty Claim Protocol and perform an internal analysis of the claimed Defect. Any Product found to be defective will be refunded, replaced or repaired at PARKITECT's discretion. Shipping costs incurred from replacement will be borne by PARKITECT. In case of replacement or refund, defective Products become the property of PARKITECT. The defective parts shall be returned to PARKITECT upon request.

May 2023 **D34C**

Resene Lumbersider Low Sheen CoolColour™

waterborne

Resene Lumbersider Low Sheen CoolColour is based on a tough 100% acrylic resin to ensure maximum durability in all exposed conditions. Imparts a natural low sheen look that is fully washable.

Resene CoolColour technology performs optimally on dark colours that are the most prone to heat build-up.

Physical properties

Vehicle type 100% acrylic

Pigmentation Titanium dioxide/fillers

Solvent Water Finish Low sheen

Colour Selected colours from the Resene Total Colour

System

45 minutes at 18°C

2 hours

Yes, dependent on surface 12 sq. metres per litre

33 microns at 12 sq. metres per litre

2; some colours may require an additional coat

Very good Good

Thermoplastic

Good Excellent Water.

c. 35 grams per litre (see Resene VOC Summary)

exterior

Typical uses

- Beams
- Block and brickwork
- Concrete and plaster
- Deckings/decks
- Fibre and particle board
- Fibre cement
- Galvanised iron
- Repaints
- Roughcast/stucco
- Timber
- Weatherboards

Performance

Dry time (minimum)

Primer required

Recoat time (minimum)

Theoretical coverage

Dry film thickness

Usual no. of coats

Abrasion resistance

Chemical resistance

Solvent resistance

Thinning and clean up

Heat resistance

Durability

VOC

Performance and limitations

- 1. Reflects heat improving the life of paint finish and substrate and improving interior conditions inside the painted structure.
- 2. Excellent adhesion to primed and natural substrates, timber, concrete and old paintwork.
- 3. Excellent as a roof coating where a low sheen finish is required.
- 4. May be used on surfaces that are to be used for the collection of drinking water.
- 5. An Environmental Choice approved product.

Limitations

- Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period. Dry and recoat times will vary with environmental conditions.
- Use Resene Wood Primer (see Data Sheet D40)
 or Resene TimberLock (see Data Sheet D48) for
 the first coat where the timber surface is showing
 signs of deterioration as a result of weathering,
 particularly on deckings.
- 3. Disconnect roof downpipes until after the first shower of rain in order to flush away surplus nontoxic wetting agents before the surface is used for the collection of drinking water.
- Areas coated with this product unmodified may not comply with New Zealand Building Code D1 3.3(d). Refer also to New Zealand Building Code D1 2.0 table 2.



Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If in doubt contact Resene.

Lumbersider Low Sheen CoolColourTM

Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease and mould. Any timber that has been exposed to weather for more than one week requires thorough sanding of the surface or treatment with Resene TimberLock (see Data Sheet D48).

If moss and mould are present, treat with Resene Moss & Mould Killer (see Data Sheet D80). Waterblasting at 21,000 kps (3000 psi) is the best surface preparation method prior to painting weathered cementitious surfaces or galvanised steel.

When painting new or old galvanised roofs, ensure the surface to be painted is thoroughly cleaned using Resene Roof and Metal Wash (see Data Sheet D88). Flush clean with freshwater. Consult Resene for technical advice on painting of old cementitious roof tiles.

Concrete

Use Resene Limelock (see Data Sheet D809) on fresh cementitious surfaces to trap any free lime and prevent the appearance of lime staining.

Timber

Where a staining type of timber exists an application of Resene Wood Primer (see Data Sheet D40) may be required. Vitex timber may take on a green colour when washed with Timber and Deck Wash (see Data Sheet D813). If this occurs apply a full wet coat of a 5% white vinegar solution, scrub and leave until the green colour disappears then wash down with copious amounts of fresh water.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, speed brush, synthetic fibre roller or spray. For optimum CoolColour performance use one coat of Resene Quick Dry or Resene Galvo-Prime depending on substrate before applying Resene Lumbersider CoolColour.

Concrete, etc

- 1. Seal where necessary with one coat of Resene Sureseal (see Data Sheet D42). Allow to dry for at least two hours. Apply one coat of Resene Quick Dry (see Data Sheet D45) and allow to dry.
- Apply two coats Resene Lumbersider Low Sheen CoolColour allowing at least two hours between coats.

Galvanised steel, Zincalume

- Apply one coat Resene Galvo-Prime (see Data Sheet D402) or Resene Galvo One (see Data Sheet D41). Resene Galvo-One may need to be overcoated in Resene Galvo-Prime (see Data Sheet D402) for optimal CoolColour effect depending on colour choice refer to Resene.
- 2. Apply two coats Resene Lumbersider Low Sheen CoolColour allowing at least two hours between coats.

Timber

- For optimum CoolColour effect, apply a full coat of an appropriate CoolColour primer, such as Resene Quick Dry (see <u>Data Sheet D45</u>), and allow to dry. For tannin-containing timber, such as cedar and redwood, apply a coat of Resene Wood Primer (see <u>Data Sheet D40</u>) before the CoolColour primer.
- 2. Apply two coats Resene Lumbersider Low Sheen CoolColour allowing at least two hours between coats.

Precautions

- 1. Ensure correct primer and/or sealer is used.
- 2. Fill all nailholes and cracked timber after priming.
- 3. Galvanised steel and Zincalume must be primed before application of Resene Lumbersider Low Sheen CoolColour.

Resene Lumbersider Low Sheen is formulated to adhere to fresh timber surfaces. Dark colours may cause the rapid drying of damp timber with the ensuing danger of warping, though this effect will be lessened when a CoolColour is selected in place of a standard colour. A coat of solventborne Resene Wood Primer (see Data Sheet D40) will slow down the rate of drying and lessen the danger of warping.



umbersider SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

the paint the professionals use